



Suction Feed Spray Gun (Code: SCFG3.85)

Gerhard suction feed spray gun spray with a lower aluminium cup tank that enables the user to spray several coverings, water or solvent based varnishes, on different media (metal, wood, masonry...) by means of a HVLP (high volume low pressure) system.

The quantity of covering product can be adjusted on the basis of its density/viscosity by means of an adjusting screw.

Turn the air cap to obtain different types of spray (vertical oval, horizontal oval or round) with a very limited overspray effect.

The spray gun features enable the user to atomise the covering product, to wrap it up in air jet and to gently and accurately settle it on the surface to be painted.

As a consequence, it enables the user to avoid or to limit the overspray effect by reducing the dispersion of spraying materials by 20-40% in the air compared to traditional systems, thus increasing the yield up to 60-80%, also to the advantage of the operator's health and the environment.

FEATURES:

- Quality suction feed spray gun is ideal for the keen hobbyist and semi professional user alike
- It is particularly designed for use with receiver compressors
- Fitted with variable fan width and flow controls
- An excellent general purpose gun for all types of metal, wood, masonry, synthetics, cellulose, enamels and metallic finishes, etc

SPECIFICATION:

- Operating air pressure: 3.85 Bar
- Air consumption: 160L/min
- Nozzle: 1.5mm
- Air Inlet: 1/4" BSP
- Pot capacity: 1 Liter

WARRANTY:

All GERHARD tools/parts carry three (3) years warranty against defects in material and workmanship. Veridian, or one of its authorized representatives, will, at Veridian's discretion, repair, or replace, any GERHARD tools/parts, without charge, if the defective or malfunctioning tool or part is returned to Veridian or one of its authorized representatives within the warranty period.

