



High-Performance Two-Cylinder Piston Airbrush Compressor with Tank

Model: ABC1.4HP

Features

- Maintenance Free, Oil-less and with very quiet operation low noise at 62dB.
- 1/4 Horsepower this unit delivers more air volume and air pressure (85 PSI) than any airbrush demands. The air tank provides smooth air flow, zero pulse
- Compact and easy to carry with the built in handle.
- True diaphragm pressure regulator with gauge and water trap filter that provides precise adjustment of airflow and will ensure clean and dry air.
- Double Switch for Automatic On/Off :

First switch position is preset for automatic turn on when air tank pressure is below 35 PSI (4 bar) and preset for automatic turn off when air tank reaches 60 PSI. The reduced running time means there will be less motor wear and less heat-related moisture enabling a longer compressor life.

Second switch position allows air tank to reach the maximum pressure of 85 PSI (6 Bar) after which the automatic safety release valve releases the excess pressure.

- Designed to produce air on demand at your regulated pressure.
- Air is drawn from the large air storage tank providing you a constant regulated pressure. There's zero pulsation because air is drawn from the tank which eliminates any pulsation effect from the pistons.
- Thermally protected by automatically turning off when the unit becomes over heated.
- Switchable for simultaneous use of two (2) air brushes
- Ideally for airbrush studios and workshops

Specifications:

Type	: Two Cylinder Piston
Power	: 1/4 Horse power, single phase
Speed	: 1450/1700rpm
Voltage	: 240V /50Hz
Air Tank Capacity	: 3.5 liter
Electric Cord	: 6 ft
Air Control	: Pressure Regulator with gauge & filter
Air Delivery	: 35 L /minutes
Maximum Pressure	: 6 Bar (85 PSI)
Air Brush	: 0.2mm nozzles
Safety	: Pressure relief valve
Connections	: with connection 1/8" BSP (2 quick release)

Supports Airbrushing for most:

- Airbrush Types
- Airbrush Applications
- Airbrush Paint and Color Media
- Levels of users from beginner to advanced artists
- Low CFM air tools, spray guns, airbrush stations

Warranty

All Hanabi machineries carry a one (1) year limited warranty against manufacturing defects.

